




CIB Forensic Science Center  
Training Seminar (Taipei, Taiwan)  
June 6-7, 2012



# Capillary Electrophoresis & Troubleshooting

**John M. Butler**  
NIST Applied Genetics Group  
National Institute of Standards and Technology  
Gaithersburg, Maryland

## Presentation Outline

- History and background on CE
- Fundamentals of CE
  - sample prep, injection, separation, detection
- ABI 3500
- Troubleshooting strategies and solutions
- Questions

**My Goal:**  
To help you understand the basic chemistry behind DNA separations and to help make CE instruments less of a "black box"

## NIST and NIJ Disclaimer

**Funding:** Interagency Agreement between the **National Institute of Justice** and NIST Office of Law Enforcement Standards


**Points of view are mine** and do not necessarily represent the official position or policies of the US Department of Justice or the National Institute of Standards and Technology.

Certain commercial equipment, instruments and materials are identified in order to specify experimental procedures as completely as possible. In no case does such identification imply a recommendation or endorsement by the National Institute of Standards and Technology nor does it imply that any of the materials, instruments or equipment identified are necessarily the best available for the purpose.

**Our publications and presentations are made available at:**  
<http://www.cstl.nist.gov/biotech/strbase/NISTpub.htm>

## Steps in DNA Analysis

*Usually 1-2 day process (a minimum of ~5 hours)*



**Collection**  
Specimen Storage

**Extraction**  
Quantitation  
Multiplex PCR  
STR Typing  
Interpretation of Results  
Database Storage & Searching  
Calculation of Match Probability

**Biological Examples:**  
Blood Stain, Buccal swab, Sample Collection & Storage

**Biological Diagrams:**  
DNA Extraction, DNA Quantitation (Gel Electrophoresis image), Multiplex PCR Amplification

**Genetics Note:** If a match occurs, comparison of DNA profile to population allele frequencies to generate a case report with probability of a random match to an unrelated individual

**Technology Diagram:**  
DNA separation and sizing, STR Typing (Male: 13,14-15,16-12,13-10,13-15,16), Interpretation of Results

**Technology Note:** DNA Database Search

## Pioneers of Capillary Electrophoresis



Stellan Hjertén  
Uppsala University

1967

First high voltage CE system (with rotating 3 mm i.d. capillaries)



James Jorgenson  
University of North Carolina

1981

First "modern" CE experiments (with 75 µm i.d. capillaries)



Barry Karger  
Northeastern University

1988/90

First DNA separations in a capillary (gel-filled/sieving polymer)

## Stellan Hjertén

Uppsala University (Sweden)



With first fully automated capillary free zone electrophoresis apparatus in 1967



In 2003 at age 75

Received his PhD (1967) under Professor Arne Tiselius who had developed moving boundary zone electrophoresis in 1937 (Noble Prize in 1948)

## A Brief History of Capillary Electrophoresis

- 1937 – Tiselius develops moving boundary electrophoresis
- 1967 – Hjertén uses rotating 3 mm i.d. tubes for CE
- **1981 – Jorgenson and Lukacs demonstrate first high performance CE separations with 75 µm i.d. capillary**
- 1988 – Karger's group shows DNA separations of single stranded oligonucleotides with gel-filled capillaries
- 1990 – Karger's group shows DNA separations with sieving polymers on DNA restriction fragments
- 1991 – Grossman expands work with sieving polymers
- 1992 – Bruce McCord starts working on PCR product separations with STR allelic ladders


## My Experience with CE, STRs, etc.

- May 1993 – began working in Bruce McCord's lab at Quantico
- Sept 1993 – developed mtDNA amplicon quantitation method (used in FBI casework from 1996 to present)
- Nov 1993 – **first demonstration of STR typing by CE** (using dual internal standards and TH01 ladder)
- July 1995 – defended Ph.D. dissertation entitled "Sizing and Quantitation of Polymerase Chain Reaction Products by Capillary Electrophoresis for Use in DNA Typing"
- July 1995 – ABI 310 Genetic Analyzer was released

## First Rapid STR Typing with Capillary Electrophoresis

Single color detection with dual internal size standards

Butler et al. (1994) *BioTechniques* 17: 1062-1070




**Performed in December 1993**

**Technology Implementation Takes Time – the FBI did not start running casework samples using STRs and CE until January 1999**

## My Experience with CE, STRs, etc. (cont.)

- 1996-1997 Developed STRBase while a postdoc at NIST
- Nov 1998 – GeneTrace Systems purchased a 310; typed several hundred samples with Profiler Plus and Cofiler kits and compared results to mass spec STR analysis
- **1999-present – Run thousands of samples with all STR kits available (except PP 1.2) and developed a number of new STR multiplex systems**
- Jan 2001 – Published "*Forensic DNA Typing: Biology and Technology behind STR Markers*" (2<sup>nd</sup> Edition in Feb 2005)
- April 2001-present – Use of ABI 3100 16-capillary array system

STR Allele Separation Can Be Performed by Gel or Capillary Electrophoresis with Detection of Fluorescent Dyes Labeling Each PCR Product



## Why Use CE for DNA Analysis?

1. Injection, separation, and detection are automated.
2. Rapid separations are possible
3. Excellent sensitivity and resolution
4. The time at which any band elutes is precisely determined
5. Peak information is automatically stored for easy retrieval



Symbol first used in Oct 1994 at the Promega meeting when I had a poster introducing the use of CE for STR typing


## Important Differences Between CE and Gels

- **Room temperature control** is essential for run-to-run precision
  - CE uses sequential rather than simultaneous separations
  - Usually need  $< 2.0\text{ }^{\circ}\text{C}$  (must inject allelic ladder regularly)
- **Lower amount of DNA loaded** (injection = nL vs  $\mu\text{L}$ ) and thus detection sensitivity must be better
- Electrokinetic injection enables **dye artifacts** (blobs) to enter the capillary or microchip CE channel and thus possibly interfere with STR allele interpretation

## More Differences between CE and Gels...

- Filling the capillary (or microchip CE channel) is analogous to pouring a gel into a tiny tube...
- Must be more clean around a CE system
  - Because the capillaries ( $\mu\text{CE}$  channels) are small, particles of dust or urea crystals can easily plug them
  - Tips of capillary cannot dry out (once buffer solutions have been run through them) for the same reasons
- **Bubbles are a BIG problem in CE as they can easily block current flow in the capillary...**

## Capillary Electrophoresis (CE)



## Typical Instruments Used for STR Typing

GeneAmp 9700

Thermal Cycler for PCR Amplification



Capillary electrophoresis instruments for separating and sizing PCR products

single capillary

16-capillary array

ABI 310

ABI 3100



©W. Butler (2011) Advanced Topics in Forensic DNA Typing: Methodology, Table 6-1

## Genetic Analyzers from Applied Biosystems

ABI Genetic Analyzer	Years Released for Human ID	Number of Capillaries	Laser	Polymer delivery	Other features
373 (gel system)	1992-2003	-	40 mW Ar+ (488/514 nm)	-	PMTs and color filter wheel for detection
377 (gel system)	1995-2006	-	40 mW Ar+ (488/514 nm)	-	CCD camera
310	1995-	1	10 mW Ar+ (488/514 nm)	syringe	Mac operating system & Windows NT (later)
3100	2000-2005	16	25 mW Ar+ (488/514 nm)	syringe	
3100-Avant	2002-2007	4	25 mW Ar+ (488/514 nm)	syringe	
3130	2003-2011	4	25 mW Ar+ (488/514 nm)	pump	
3130xl	2003-2011	16	25 mW Ar+ (488/514 nm)	pump	
3500	2010-	8	10-25 mW diode (505 nm)	new pump	110V power, RFID-tagged reagents, .hld files, normalization & 6-eye detection possible
3500xl	2010-	24			
3700	2002-2003	96	25 mW Ar+ (488/514 nm)	cuvette-based	Split beam technology
3730	2005-	48	25 mW Ar+ (488/514 nm)	pump	
3730xl	2005-	96	25 mW Ar+ (488/514 nm)	pump	

Information courtesy of Michelle S. Shepherd, Applied Biosystems, LIFE Technologies.

## ABI Genetic Analyzer Usage at NIST

(All instruments were purchased using NIJ funds)



### ABI 310 Single capillary

- 1<sup>st</sup> was purchased in 1996 as Mac (A230, now B233)
- 2<sup>nd</sup> was purchased in June 2002 as NT (B261)



### ABI 3100 → 3130xl 16 capillaries

- 1<sup>st</sup> purchased in April 2001 as ABI 3100
  - upgraded to 3130xl in Sept 2005
  - Located in a different room (A230, now B219)
- 2<sup>nd</sup> purchased in June 2002 as ABI 3100
  - Original data collection (v1.0.1) software retained
  - updated to 3130xl in Jan 2007 (B219, now B261)



### ABI 3500 8 capillaries

- Purchased Nov 2010 (B233)

### DNA Samples Run at NIST

we have processed >100,000 samples (from 1996-present)

- **STR kits**
  - Identifier, PP16, PP16HS, Identifier Plus, Identifier Direct, Profiler Plus, Cofiler, SGM Plus, ESI/ESX 17, SE33 monoplex
- **Research & development on new assays**
  - **STRs:** Y-STR 20plex, MeowPlex, miniSTRs, 26plex
  - **SNPs:** SNaPshot assays: mtDNA (one 10plex), Y-SNPs (four 6plexes), Orchid SNPs (twelve 6plexes), ancestry SNPs (two 12plexes), SNPforID (one 29plex), SNPplex (one 48plex)
- **DNA sequencing**
  - Variant allele sequencing

We have a unique breadth and depth of experience with these instruments...




### Review Article on STRs and CE

pdf available from <http://www.cstl.nist.gov/biotech/strbase/NISTpub.htm>


Electrophoresis 2004, 25, 1397-1412	Contents
<b>Review</b>	1 Introduction ..... 1397
<b>John M. Butler<sup>1</sup></b>	1.1 General aspects ..... 1397
<b>Eric Bue<sup>2</sup></b>	1.2 Early work with CE ..... 1400
<b>Federica Crivellenti<sup>3*</sup></b>	2 Sample preparation and injection ..... 1401
<b>Bruce R. McCord<sup>4</sup></b>	3 The polymer separation matrix ..... 1402
	3.1 The polymer separation matrix ..... 1403
	3.2 The buffer ..... 1403
	3.3 The capillary ..... 1404
<small><sup>1</sup>National Institute of Standards and Technology, Biotechnology Division, Gaithersburg, MD, USA</small>	4 Sample detection ..... 1405
<small><sup>2</sup>Vermont Forensic Laboratory, Waterbury, VT, USA</small>	5 Sample interpretation ..... 1406
<small><sup>3</sup>Ohio University, Department of Chemistry, Athens, OH, USA</small>	5.1 Software used ..... 1406
	5.2 Assessing resolution of DNA separations ..... 1406
	6 Applications of forensic DNA testing ..... 1407
	6.1 Forensic casework ..... 1407
	6.2 DNA databasing ..... 1408
	7 Increasing sample throughput ..... 1408
	7.1 Capillary array electrophoresis systems ..... 1408
	7.2 Microchip CE systems ..... 1409
	7.3 Future methods for DNA typing with STR markers ..... 1410
	8 References ..... 1410

### Analytical Requirements for STR Typing

Butler et al. (2004) Electrophoresis 25: 1397-1412


- Fluorescent dyes must be **spectrally resolved** in order to distinguish different dye labels on PCR products
  - 
- PCR products must be **spatially resolved** – desirable to have single base resolution out to >350 bp in order to distinguish variant alleles
  - 
- High **run-to-run precision** – an internal sizing standard is used to calibrate each run in order to compare data over time
  - 

### Steps in STR Typing with ABI 310/3100



Butler, J.M. (2005) Forensic DNA Typing, 2<sup>nd</sup> Edition, Figure 13.8, © Elsevier Science/Academic Press

### Detection with Multiple Capillaries (Irradiation for Capillary Arrays)



ABI 3100, 3130, 3100Avant      ABI 3700      MegaBACE

### Process Involved in 310/3100 Analysis

- **Separation**
  - Capillary – 50um fused silica, 43 cm length (36 cm to detector)
  - POP-4 polymer – Polydimethyl acrylamide
  - Buffer - TAPS pH 8.0
  - Denaturants – urea, pyroldinone
- **Injection**
  - electrokinetic injection process (formamide, water)
  - importance of sample stacking
- **Detection**
  - fluorescent dyes with excitation and emission traits
  - CCD with defined virtual filters produced by assigning certain pixels

# Separation


## Ohm's Law

- $V = IR$  (where  $V$  is voltage,  $I$  is current, and  $R$  is resistance)
- Current, or the flow of ions, is what matters most in electrophoresis
- CE currents are much lower than gels because of a higher resistance in the narrow capillary
- CE can run a higher voltage because the capillary offers a higher surface area-to-volume ratio and can thus dissipate heat better from the ion flow (current)

## DNA and Electrophoresis

"From a practical point of view it is disappointing that electrophoresis cannot be used to fractionate or analyze DNA's on the basis of size" Olivera, *Biopolymers* 1964, 2, 245

$$\mu_{ep} = q/6\pi\eta r \quad \text{small ions with high charge move fastest}$$



As size increases so does charge!




Figure 12.4. J.M. Butler (2005) *Forensic DNA Typing*, 2<sup>nd</sup> Edition © 2005 Elsevier Academic Press

## Separation Issues

- **Electrophoresis buffer** –
  - Urea for denaturing and viscosity
  - Buffer for consistent pH
  - Pyrrolidone for denaturing DNA
  - EDTA for stability and chelating metals
- **Polymer solution** -- POP-4 (but others work also)
- **Capillary wall coating** -- dynamic coating with polymer
  - Wall charges are masked by methyl acrylamide
- **Run temperature** -- 60 °C helps reduce secondary structure on DNA and improves precision. (Temperature control affects DNA sizing)

## What is in POP-4 and Genetic Analyzer Buffer?

© 1997 Oxford University Press *Nucleic Acids Research*, 1997, Vol. 25, No. 19 3925-3929

### Improved single-strand DNA sizing accuracy in capillary electrophoresis

Barnett B. Rosenblum\*, Frank Oaks, Steve Menchen and Ben Johnson

PE Applied Biosystems, 850 Lincoln Centre Drive, Foster City, CA 94404, USA


Received May 29, 1997; Revised and Accepted August 6, 1997


See also Wenz *et al.* (1998) *Genome Research* 8: 69-80

**POP-4** (4% poly-dimethylacrylamide, 8 M urea, 5% 2-pyrrolidone)


US Patent 5,552,028 covers POP-4 synthesis

Running buffer contains 100 mM TAPS and 1 mM EDTA (adjusted to pH 8.0 with NaOH) TAPS = N-Tris-(hydroxymethyl)methyl-3-aminopropane-sulfonic acid








- ### How to Improve Resolution?
1. Lower Field Strength
  2. Increase Capillary Length
  3. Increase Polymer Concentration
  4. Increase Polymer Length
- All of these come at a cost of longer separation run times



# Injection





### Sample Conductivity Impacts Amount Injected

$$[DNA_{inj}] = \frac{Et(\pi r^2) (\mu_{ep} + \mu_{eof}) [DNA_{sample}] (\lambda_{buffer})}{\lambda_{sample}}$$

**[DNA<sub>inj</sub>]** is the amount of sample injected  
**E** is the electric field applied  
**t** is the injection time  
**r** is the radius of the capillary  
**μ<sub>ep</sub>** is the mobility of the sample molecules  
**μ<sub>eof</sub>** is the electroosmotic mobility

**[DNA<sub>sample</sub>]** is the concentration of DNA in the sample  
**λ<sub>buffer</sub>** is the buffer conductivity  
**λ<sub>sample</sub>** is the sample conductivity

Cl<sup>-</sup> ions and other buffer ions present in PCR reaction contribute to the sample conductivity and thus will compete with DNA for injection onto the capillary

Butler et al. (2004) Electrophoresis 25: 1397-1412


### Steps Performed in Standard Module

See J.M. Butler (2005) *Forensic DNA Typing*, 2<sup>nd</sup> Edition; Chapter 14

- **Capillary fill** – polymer solution is forced into the capillary by applying a force to the syringe
- **Pre-electrophoresis** – the separation voltage is raised to 10,000 volts and run for 5 minutes;
- **Water wash of capillary** – **capillary is dipped several times in deionized water to remove buffer salts that would interfere with the injection process**
- **Sample injection** – the autosampler moves to position A1 (or the next sample in the sample set) and is moved up onto the capillary to perform the injection; a voltage is applied to the sample and a few nanoliters of sample are pulled onto the end of the capillary; the default injection is 15 kV (kilovolts) for 5 seconds
- **Water wash of capillary** – capillary is dipped several times in waste water to remove any contaminating solution adhering to the outside of the capillary
- **Water dip** – capillary is dipped in clean water (position 2) several times
- **Electrophoresis** – autosampler moves to inlet buffer vial (position 1) and separation voltage is applied across the capillary; the injected DNA molecules begin separating through the POP-4 polymer solution
- **Detection** – data collection begins; raw data is collected with no spectral deconvolution of the different dye colors; the matrix is applied during Genescan analysis

### Comments on Sample Preparation

- Use high quality formamide (<100 μS/cm)
- Denaturation with heating and snap cooling is not needed (although most labs still do it...)
- **Post-PCR purification reduces salt levels and leads to more DNA injected onto the capillary**



### Why MiniElute increases peak heights


- QIAGEN MiniElute **reduces salt levels in samples causing more DNA to be injected**
- **Requires setting a higher stochastic threshold to account for the increased sensitivity**

QIAGEN  
Pure DNA fragment

Smith, P.J. and Ballantyne, J. (2007) Simplified low-copy-number DNA analysis by post-PCR purification. *J. Forensic Sci.* 52: 820-829

### Stochastic Effects and Thresholds


Regular Injection      Injection Following Desalting (MiniElute)



When PCR amplifying low levels of DNA, allele dropout may occur



False homozygote




Stochastic threshold must be raised




# Detection


### Optics for ABI 310




### Fluorescence



### Methods for Fluorescently Labeling DNA




The polymerase chain reaction (PCR) is used to amplify STR regions and label the amplicons with fluorescent dyes using locus-specific primers








ABI Fluorescent Dyes Used in Four-Color Detection



Fluorescent Emission Spectra for ABI Dyes



Importance of Spectral Calibration



Matrix with 4 Dyes on ABI 310

$I_{540} = bx_b + gy_b + yz_b + rw_b$  intensity of blue  
 $I_{560} = bx_g + gy_g + yz_g + rw_g$  intensity of green  
 $I_{580} = bx_y + gy_y + yz_y + rw_y$  intensity of yellow  
 $I_{610} = bx_r + gy_r + yz_r + yw_r$  intensity of red


Where  
 b is the %blue labeled DNA  
 g is the %green labeled DNA, etc.





x,y,z,w are the numbers in the matrix (sensitivity to each color)

PDP4STRMODF				
Reactions				
	B	G	Y	R
B	1.0000	0.8502	0.1360	0.0009
G	0.8300	1.0000	0.7622	0.0051
Y	0.6416	0.8324	1.0000	0.1102
R	0.4493	0.6484	0.7851	1.0000

If you solve xyzw for each dye individually  
 Then you can determine dye contribution for any mixture

5 x 5 matrix for 5-dye analysis on ABI 310






- ### Maintenance of ABI 310/3100/3130
- Syringe – leaks cause capillary to not fill properly
  - Capillary storage & wash – **it dries, it dies!**
  - Pump block – cleaning helps insure good fill
  - Change the running buffer regularly
- YOU MUST BE CLEAN AROUND A CE!**

- ### Protocols Used for STR Typing
- Most forensic DNA laboratories follow PCR amplification and CE instrument protocols provided by the manufacturer
  - Comments
    - Lower volume reactions may work fine and reduce costs
    - No heat denaturation/snap cooling is required prior to loading samples into ABI 310 or ABI 3100
    - Capillaries do not have to be thrown away after 100 runs
    - POP-4 polymer lasts much longer than 5 days on an ABI 310
    - **Validation does not have to be an overwhelming task**

# ABI 3500 Genetic Analyzer

## ABI 3500 Genetic Analyzer




### New Features of the ABI 3500 CE

- an improved polymer delivery pump design,
- ready-to-use consumables and containers,
- Radio Frequency Identification (RFID) consumable tracking,
- quality control software features for rapid identification and re-injection of failed samples,
- increased throughput,
- new laser technology,
- reduced power requirements,
- peak height normalization,
- intuitive user software, and integrated primary analysis software,
- improved peak height uniformity across capillaries, runs and instruments
- **6-dye channel capability**

- **3500 (8 capillary)**
- **3500xl (24 capillary)**

## Details of the new ABI 3500

No lower pump block (fewer air bubbles)



Improved sealing for better temperature control (improved precision?)



Better seal around the detector

Reagents prepackaged with RFID tags



## Primary Differences Between 31xx and 3500

### 31xx Instruments

- Argon ion (Ar+) lasers with 488/514 nm wavelengths for fluorescence excitation
- 220V power requirement
- **Optimal signal intensity 1500-3000 RFU**
- **Data signal depressed 4-fold during data collection**
- Currently validated and operational in most forensic laboratories (.fsa files)

### 3500 Instruments

- Single-line 505 nm, solid-state long-life laser
- Smaller footprint
- 110V power requirement
- **Optimal signal intensity can approach 20,000-30,000 RFU**
- Normalization of instrument-to-instrument signal variability
  - Ability to increase or decrease overall signal
- Requires the use of GeneMapper IDX v1.2 (.hid files)

## ABI 3500 'Dash Board' Data Collection

**Gauges**

POP7 Polymer: 384 / 576 / 710  
 AB 3500 Buffer - (Anode): 5 Days Remaining (58 Injections Remaining)  
 AB 3500 Buffer - (Cathode): 5 Days Remaining (58 Injections Remaining)  
 50cm - 24 cap Array: 43 Injections Performed

Consumable	Name	Status	Days on Instrument	Expiration Date	Lot Number	Part Number
Polymer	POP7	634 Samples Remaining (24 Injections Remaining)	0	04-Sep-2009 11:15AM	15A081	4303114
Buffer	AB 3500 Buffer	5 Days Remaining	2	08-May-2009 11:15:00 AM	51-B-14051	4303728
Buffer	AB 3500 Buffer	5 Days Remaining	2	08-May-2009 11:15:00 AM	51-B-14051	4303728
Capillary Array	50cm - 24 cap	132 Injections Remaining	0	05-Jun-2009 11:15:00 AM	0715-47H-B	4482256


**Tracks the numbers of samples for 'QC purposes'**



Maintenance Name	Priority	Notification Date	Description	Action
Clean Autosampler	MS01	17-Mar-2009 12:00:00 AM	Clean Autosampler	✓ X
Flush Pump Trap	MS01	17-Mar-2009 12:00:00 AM	Flush Pump Trap	✓ X
Run Performance Check	MS01	17-Mar-2009 12:00:00 AM	Run Fragment#2 and/or Sequencing Performance Check	✓ X
Check Disk Space	MS01	17-Mar-2009 12:00:00 AM	Check Computer for Disk Space	✓ X
Perform Planned Maintenance	MS01	17-Mar-2009 12:00:00 AM	Perform Planned Maintenance	✓ X

[https://www3.appliedbiosystems.com/cms/groups/portal/documents/web\\_content/cms\\_064299.jpg](https://www3.appliedbiosystems.com/cms/groups/portal/documents/web_content/cms_064299.jpg)

## ABI 3500 Generates Excellent Data

STR typing with a 1:7 mixture using 36 cm array and POP4





# Troubleshooting: Strategies and Solutions

Bruce McCord's *Profiles in DNA* Article

PROFILES IN DNA | Volume 6 (2), Sept 2003, pp. 10-12

**TECH TIPS**

**Troubleshooting Capillary Electrophoresis Systems**

By Bruce McCord  
Associate Professor of Forensic Chemistry, Ohio University, Athens, Ohio

**INTRODUCTION**  
The development of capillary electrophoresis (CE) has played a key role in bringing about the modern application of DNA typing. Forensic laboratories are the beneficiaries of this new technology, but many practitioners are not fully aware of the underlying principles of the CE system. This article attempts to address the important issues in CE separations to aid analysts in troubleshooting problematic separations. The key to producing good DNA separations is to understand the principles underlying the injection, separation and detection of each allele. These points are addressed below.

**SEPARATION**  
DNA analysis by CE is performed using entangled polymer buffers (Figure 1). These buffers can be easily pumped into a capillary prior to a separation and pumped out at its conclusion, providing a fresh separation matrix for each run. A typical buffer for forensic DNA separation contains 4% polydimethyl acrylamide (pDMA), buffered to pH 8

*The key to producing good DNA separations is to understand the principles underlying the injection, separation and detection of each allele.*

Applied Biosystems  
Forensic News

October 2007 FAS Corner

[http://marketing.appliedbiosystems.com/images/forensic/volume11/docs/52808\\_FN\\_FAS\\_r3.pdf](http://marketing.appliedbiosystems.com/images/forensic/volume11/docs/52808_FN_FAS_r3.pdf)

Troubleshooting Amplification and Electrophoresis of the AmpF/STR® Kits

One of the key responsibilities of our Human Identification Field Application Specialists is to troubleshoot results obtained using any of the AmpF/STR® kits on any Applied Biosystems validated instrument platform.

**Troubleshooting Electrophoresis**

Below are some common observations that may be seen during electrophoresis of AmpF/STR® kit PCR products:


- Spikes/Extraneous peaks
- No signal or low signal
- Loss of resolution
- Arcing
- Low reproducibility
- Contamination
- Baseline issues
- Poor peak morphology

Spikes or Extraneous Peaks

## External Factors

- Room temperature
  - Variations in room temperature can cause mobility shifts with band shifts and loss of calibration
  - Temperature is also important due to effects of high humidity on electrical conductance
- Cleanliness
  - Urea left in sample block can crystallize and catalyze further crystal formation causing spikes, clogs and other problems.
  - Best bet is to keep polymer in system and not remove or change block until polymer is used up.


### Effect of temperature on allele size



Slope is 0.14 bases/degree centigrade  
 Therefore a small change in temperature has a big effect  
 (A 1-2 degree shift in temperature of the heat plate can produce an OL allele)


Hartzell, B., et al. (2003). Response of short tandem repeat systems to temperature and sizing methods. *Forensic Science International*, 133, 228-234.

### D18S51




slide 34


### D21S11




### Temperature Effects Off-Ladder "OL Alleles"




### "OL alleles" - look at the 250 peak



### "OL allele re-injected"



### And the 250 peak...



### Temperature Probes

Frig/Freeze Monitors \$240  
 #DT-23-33-80 – USB Temperature Datalogger  
 PLUS Software \$79.00 (#DT-23-33-60)  
 Room Monitors, # DT-23039-52 – USB  
 Temperature-Humidity Datalogger \$91.00  
 (Cole Parmer, Vernon Hills IL)


Refrigerator and freezer monitoring




Room temperature monitoring




### Monitoring Instrument Room Temperature Fluctuations



### Poor Temperature Control Causes DNA Sizing Imprecision




### Use of Second Allelic Ladder to Monitor Potential Match Criteria Problems



### Cleanliness



- Urea sublimates and breaks down to ionic components - these find a path to ground
- Similarly wet buffer under a vial creates paths to ground
- Capillary windows must be clear or matrix effects will occur
- Laser will often assist in this process
- Vial caps will transfer low levels of DNA to capillary



## Instrumental Factors

- Optical System
  - Sensitivity changes with age, capillary diameter, capillary cleanliness, instrument calibration
- Fluidic System
  - Effects of bubbles, dust, urea crystals, leaks in syringe and capillary ferrule
- Matrix Calculations
  - Changes in buffer, optics, sample dye can alter the software calibrations
- Capillary Problems
  - Chemisorbed materials on capillary surface can produce osmotic flow, DNA band broadening and inconsistent resolution (meltdowns)

## The Detection Window



## Beware of Urea Crystals



Urea crystals have formed due to a small leak where the capillary comes into the pump block

Urea sublimates and can evaporate to appear elsewhere

Use a small balloon to better grip the ferrule and keep it tight


Pump block should be well cleaned to avoid problems with urea crystal formation

## Buffer Issues


- The buffer and polymer affect the background fluorescence- affecting the matrix
- Urea crystals and dust may produce spikes
- High salt concentrations may produce reannealing of DNA
- High salt concentrations affect current
- Low polymer concentrations affect peak resolution

## Meltdowns can be permanent or transitory

as we have seen these may result from sample contamination effects



No! The next injection looks fine...



## Meltdowns may be the result of


- Bad formamide
- Excess salt in sample/renaturation
- Water in the polymer buffer
- **Syringe leak** or bottom out
- Poisoned capillary
- Conductive polymer buffer due to urea degradation
- Crack/shift in capillary window
- Detergents and metal ions

## Troubleshooting benchmarks

- **Monitor run current**
- Observe syringe position and movement during a batch
- Examine ILS (ROX) peak height with no sample
- Observe "250 bp" peak in GS500 size standard
- Monitor resolution of TH01 9.3/10 in allelic ladder and size standard peak shapes
- **Keep an eye on the baseline signal/noise**
- Measure formamide conductivity
- Reagent blank – **are any dye blobs present?**
- See if positive control DNA is producing typical peak heights (along with the correct genotype)

## Measurement of Current





- $V/I = R$  where R is a function of capillary diameter, [buffer], and buffer viscosity
- In a CE system the voltage is fixed, thus changes in resistance in the capillary will be reflected in the current observed
- Air bubbles, syringe leaks, alternate paths to ground, changes in temperature, changes in zeta potential, and contamination, will be reflected in the current
- A typical current for a CE system with POP4 buffer is **8-12  $\mu\text{A}$**  (microamps)



## Syringe Travel

- The ABI 310 instrument also keeps track of the position of the syringe (in the log file)
- Depending on the resistance to flow, the syringe will travel different lengths
- Syringe leaks may be reflected in a longer distance traveled prior to each injection
- These leaks occur around the barrel of the syringe and at the connection to the capillary block






Conclusion:  
**Troubleshooting is more than following the protocols**

**It means keeping watch on all aspects of the operation**

1. Monitoring conductivity of sample and formamide
2. Keeping track of current and syringe position in log.
3. Watching the laser current
4. Watching and listening for voltage spikes
5. Monitoring room temperature and humidity



## Acknowledgments

### ***NIST Human Identity Project Team***

*Leading the Way in Forensic DNA...*



John Butler



Erica Butts



Mike Coble



Dave Duwer



Becky Hill



Kevin Kiesler



Margaret Kline



Pete Vallone

**Funding from an interagency agreement between the National Institute of Justice and the NIST Office of Law Enforcement Standards and also from the FBI**

**Many wonderful collaborators from industry, university, and government laboratories.**


**Bruce McCord** (Florida International University) for many of the slides

## Thank you for your attention

### Contact Information

**John Butler**  
NIST Fellow  
Group Leader of Applied Genetics  
[john.butler@nist.gov](mailto:john.butler@nist.gov)  
**+1-301-975-4049**

<http://www.cstl.nist.gov/biotech/strbase>



**Our team publications and presentations are available at:**  
<http://www.cstl.nist.gov/biotech/strbase/NISTpub.htm>